




Testing guide for 3119 ASE Wiring and line faults


Page 1 - Description flow chart






Testing guide for 3119 ASE Wiring and line faults

Page 2 - Photo flow chart




Line Fault Indicator




Input Status detail



Test 1 – Normal State – Short input



Test 2 – Alarm/Active State – 470ohm resistor on input



Test 3 – Wiring check – Test cable

